


ASSEMBLY INSTRUCTION



ИНСТРУКЦИЯ A1660PL-4AB



Mode	Accessories View	Quantity
Α		8
В		8
С		16
D		8
E	- ₩	8
F	******	8
G		8
Н		8
I	-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0	8
J		8
K	*************************************	8
L		6
N		1